

[RETURN]

Press this button to return back to game Menu

[DIRECTION]

In Game Menu interface,press this button to choose the game , or in Game interface, press this button to choose "role" "Game Objects" etc.

[SELECT]

In Game Menu Interface,press this button to select the game, or in Game interface, press this button to select "role" "Game Objects" etc

[START]

After enter in to Game Interface,press this button to start Game.

[A,B,C,D]


Undefined Button , Common function is Jump , Kick ,Beat etc in Game Interface.

NOTE:Due to different games, Combination buttons function can not be defined accurately.



2 in 1 Games joystick

Connection Diagram



\*How to connect the DOOR TRIGGER wire

Use yellow wire to connect door trigger positive power, then connect blue wire when door galing trigger in positive power and black wire when in negative power.