


Seat Heaters

Component Location Index

NOTE: LHD type is shown, RHD type is similar.



- |  |   |
|--|---|
| 1 DRIVER'S SEAT CUSHION HEATER   | Test, <a href="#">page 22A-184</a>  |
| 2 DRIVER'S SEAT HEATER RELAY   | Test, <a href="#">page 22A-184</a>  |
| 3 FRONT PASSENGER'S SEAT HEATER RELAY                                  | Test, <a href="#">page 22A-184</a>  |
| 4 FRONT PASSENGER'S SEAT CUSHION HEATER                                | Test, <a href="#">page 22A-184</a>  |
| 5 SEAT HEATER MAIN RELAY<br>[Wire colors: GRV, RED /BLK, BLK, BLK/YEL] | Test, <a href="#">page 22A-60</a>   |
| 6 SEAT HEATER SWITCH   | Test, <a href="#">page 22A-185</a><br>Replacement, <a href="#">page 22A-185</a> |